NEED MORE HELP?

For the latest support info and online User Manuals visit **jabra.com/motionuc**

TOLL FREE Customer Contact Details:

EUROPE

Belgique/Belgie	+32 28080766
Danmark	+45 69918794
Germany	+49 30896778991
Switzerland	+41 435002460
Spain	+34 911875539
France	+33 182880251
Italy	+39 0662207674
Luxembourg	+45 35256540
Netherlands	+31 208080962
Norway	+47 22577785
Austria	+43 720880558
Portugal	+45 35256540
Finland	+45 35256540
Sweden	+46 852507012
United Kingdom	+44 2033180070
International	+45 35256540

EMAIL ADDRESSES

Austria	support.at@jabra.com
Belgium	support.be@jabra.com
Deutsch	support.de@jabra.com
English	support.uk@jabra.com
Français	support.fr@jabra.com
Italiano	support.it@jabra.com
Nederlands	support.nl@jabra.com
Español	support.es@jabra.com
Scandinavian	support.no@jabra.com
Switzerland	support.ch@jabra.com
Россия	support.ru@jabra.com
Polska	support.pl@jabra.com

Design Registration Pending International

For more information, please visit
www.jabra.com

81-03760 A

Jabra MOTION UC
Jabra MOTION UC+

Jabra®
YOU'RE ON

GET STARTED IN UNDER

5 MINUTES

jabra.com/motionuc

A BRAND BY

GN Netcom

© 2013 GN Netcom A/S (North America: GN Netcom US, Inc.) All rights reserved. Jabra® is a registered trademark of GN Netcom A/S. All other trademarks included herein are the property of their respective owners. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. (Design and specifications subject to change without notice).

Made in China

MODEL: BTE6

CE

АЯ46

Bluetooth®

www.jabra.com

ENGLISH.....2
NEDERLANDS 8

1 HOW TO CONNECT

CONNECTING WITH THE JABRA LINK 360

Plug the Jabra Link 360 into any available USB port on your PC, and open the flip boom-arm on the headset to connect.



CONNECTING WITH A BLUETOOTH DEVICE

1. While pressing the **Call** button, open the flip boom-arm. Release the **Call** button when the Bluetooth light flashes blue.
2. Wear on the ear and follow the voice-guided connection instructions.





CONNECTING WITH AN NFC DEVICE

To pair using an NFC-enabled device, refer to the online user manual.

2 HOW TO WEAR

HEIGHT ADJUSTMENT

Get the perfect fit for your ear by adjusting the height of the speaker up or down.



LEFT OR RIGHT EAR WEARING STYLE

The headset can be worn on the left or right ear. To switch ear:

1. Pull the speaker all the way down.
2. Rotate the speaker 180°.
3. Twist the eargel around to fit.



3 HOW TO USE



Did you know?

You can download the User Manual at jabra.com/motionuc to learn more about additional features such as Advanced Multiuse, NFC and motion sensor interactivity. The Jabra Connect app is now available for your android or iOS device.

	On/off	Open or close the flip boom-arm
	Answer call	Open the flip boom-arm, or tap the **Call** button if the boom-arm is open
	End call	Close the boom-arm, or tap the **Call** button
	Reject call	Double-tap the **Call** button when there is an incoming call
	Redial last number	Double-tap the **Call** button when not on a call
	Adjust speaker volume	Slide a finger up/down the **Volume** touch-sensitive panel
	Voice commands	Tap the **Voice and Mute microphone** button when not on a call, until you hear 'Geef een opdracht!'. Say 'Wat kan ik zeggen?' for a list of voice commands
	Mute microphone	Tap the **Voice and Mute microphone** button during a call

4 MOTION SENSOR CONTROLS

CALL ASSIST

Pick up the headset from the desk to your ear to automatically answer an incoming call.



HIBERNATION MODE

To extend battery life, the headset will enter hibernation mode when it has not been moved for 60 minutes (when Bluetooth connected) or 5 minutes (when not Bluetooth connected).



Note: Motion sensor controls are default-enabled, and can be disabled in Jabra PC Suite and/or the Jabra Connect app.

5 TRAVEL & CHARGE KIT

The Travel & Charge Kit stores and charges the headset.

CHARGING

Dock the headset and plug the dock into a power supply using the micro-USB cable or the wall charger.

Note: It takes 2 hours to fully charge the headset.





1 VERBINDEN

VERBINDEN MET DE JABRA LINK 360

Sluit de Jabra Link 360 aan op een vrije USB-poort van uw PC en klap de microfoonarm op de headset uit om te verbinden.



VERBINDEN MET EEN BLUETOOTH-APPARAAT



1. Klap de microfoonarm open terwijl u de **Bellen**-toets ingedrukt houdt. Laat de **Bellen**-toets los zodra het Bluetooth-lampje blauw knippert.
2. Draag de headset op het oor en volg de gesproken verbindingsinstructies.



VERBINDEN MET EEN NFC-APPARAAT

Raadpleeg om te koppelen met een NFC-apparaat de online handleiding.

2 DRAGEN



HOOGTE VERSTELLEN

Voor de optimale pasvorm voor uw oor, verstelt u de hoogte van de luidspreker.

DRAAGSTIJL LINKER OF RECHTEROOR

De headset kan zowel op het linker- als het rechteroor gedragen worden. Om het andere oor te gebruiken:

1. Trek de luidspreker helemaal omlaag.
2. Draai de luidspreker 180°.
3. Draai de oorgel om.



3 GEBRUIKEN



Wist u dat...?

U kunt de handleiding downloaden op jabra.com/motionuc voor meer informatie over extra functies, zoals Advanced Multiuse, NFC en interactiviteit van de bewegingssensor. De Jabra Connect app is nu beschikbaar voor uw android en iOS-apparaat.

	Aan/uit	Klap de microfoonarm in of uit
	Oproep beantwoorden	Klap de microfoonarm uit of tik op de **Bellen**-toets als de microfoonarm al uitgeklapt is
	Oproep beëindigen	Klap de microfoonarm in of tik op de **Bellen**-toets
	Oproep weigeren	Dubbeltik op de **Bellen**-toets wanneer er een oproep binnenkomt
	Laatste nummer opnieuw kiezen	Dubbeltik op de **Bellen**-toets wanneer u niet aan de telefoon bent
	Het luidsprekervolume regelen	Wrijf met uw vinger omhoog of omlaag over het **Volume**-aanraakpaneel
	Stemcommando's	Tik op de toets **Stemcommando's en Mute microfoon** wanneer u niet aan de telefoon bent, totdat u 'Geef een opdracht!' hoort. Zeg 'Wat kan ik zeggen?' om de lijst met stemcommando's te beluisteren.
	Mute-stand microfoon inschakelen	Tik tijdens een gesprek op de toets **Stemcommando's en Mute microfoon**

4 BEWEGINGSSENSORBEDIENING

OPROEPONDERSTEUNING

Breng de headset van het bureau naar uw oor om de binnenkomende oproep automatisch te beantwoorden



SLUIMERSTAND

Om de levensduur van uw batterij te verlengen, schakelt de headset zich in de sluimerstand zodra hij 60 minuten (met Bluetooth-verbinding) of 5 minuten (zonder Bluetooth-verbinding) niet bewogen is.



Opmerking: Bewegingssensorbediening is standaard ingeschakeld. U kunt deze functie uitschakelen met Jabra PC Suite en/of de Jabra Connect app.

5 REIS- EN OPLAADKIT

Met de Reis- en oplaadkit kunt u uw headset opbergen en opladen.

OPLADEN

Plaats de headset in het basisstation en sluit het basisstation aan op een stroombron via de micro USB-kabel of het stopcontact.



Opmerking: Het duurt 2 uur om de headset volledig op te laden.